


Tips for using without Lego

The R4G web app can also be used with other hardware combinations. Important elements are:

- BBC Micro:bit
- Motor Driver Board
- Buzzer
- Chassis

In the R4G we used the [Waveshare Motor Driver Board](#). The software also works with the motorboards from [Keyestudio](#) and [ElecFreaks](#). The corresponding HEX files must be loaded onto the microbit (e.g. the file r4g-microbit-ef.hex for the motor board from ElecFreaks). The files can be found at <https://github.com/ZimdVienna/Robo4girls/tree/master/microbit>.



If you want to use a buzzer, it is best to use the one from our order list (https://www.netidee.at/sites/default/files/2019-12/R4G_Bill_of_materials_0.pdf), because some buzzers are very quiet. Connect the pin 0 and GND pin of your micro: bit to the buzzer as shown in this circuit diagram: <https://github.com/ZimdVienna/Robo4girls/>.

For the body, we recommend the [diymore 2WD robot smart car chassis](#), which we know is compatible with our other hardware. See also our order list.

The following elements from our "tool case" can be used:

1. **Firmware:** The Micro: bit must be connected to a computer via USB and one of the files R4G_MICROBIT.hex must be transferred to the Micro: bit. The instructions for this can be found at <https://github.com/ZimdVienna/Robo4girls>, the HEX files at <https://github.com/ZimdVienna/Robo4girls/tree/master/microbit>.
2. **Test instructions.** It is located at <https://www.netidee.at/sites/default/files/2019-12/R4G-Pruefanleitung-v5-de.pdf>, the chapter is relevant: **Check all functions**.
3. **Course guide Roberta with R4G:** Here, page 8 describes how programming using the R4G web app works: https://www.netidee.at/sites/default/files/2019-12/Workshop-Leitfaden_R4G.pdf.
4. **R4G app:** The functionality of the software is very simple and a very good start, as we have heard back several times during the project. It is explained in the guide above. The R4G app can be found at <https://zimdvienna.github.io/Robo4girls/>.
5. To program the R4G robots, you also need tablets and WiFi. Since this is often not available in schools, we always have a "cube" with a fast SIM card. It makes sense for the teacher to work with a tablet with a micro HDMI output as well as a projector and an HDMI to micro HDMI cable, so that the functionality of the software can be demonstrated. (But not all tablets need such an exit.)